

Chart – Wireless sensors that can be taught-in in wireless actuators



Sensors Actuators	Pushbuttons and hand-held transmitters	Transmitter modules	Card switch, pull switch and smoke alarm	Window/door contact	Hoppe window handle	Motion sensors	Brightness sensors	Temperature controller/sensors	Control from a PC using FVS Software
	FT2S, FT4F FT4, FFT55Q, FMT55, FHS4 FHS6, FHS8 FHS12, FMH2 FMH4, FMH8	FSM12 F8S12 FSM61 FTS12EM FSU55D FSU12	FKF FKC FZS FRW	FTK	FHF	FBH63 FABH63	FABH63 FAH60 FAH63 FBH63 FIH63AP	FTR55H FTR55D FTF55 FUT55D FAFT60	
FFR12-12 V DC	X	X							X
FHK12-12 V DC	X			X	X	X		X	X
FKR12/1-10V	X	X				X	X		X
FKR12UD-12 V DC	X	X				X	X		X
FLS12/1-10 V	X	X							X ²⁾
FLS12UD-12 V DC	X	X							X ²⁾
FMS12-12 V DC	X	X	X						X
FMZ12-12 V DC	X	X	X	X	X				X
FSA12-12 V DC	X	X	X	X	X	X			X
FSB12-12 V DC	X	X		X	X		X		X ²⁾
FSG12/1-10V	X	X							X
FSR12-12 V DC	X	X	X	X	X	X	X		X
FSR12-4x-12 V DC	X	X	X	X	X	X	X		X
FTN12-12 V DC	X	X		X		X			X
FUD12/800 W	X	X							X ²⁾
FUD12NPN-12 V DC	X	X							X ²⁾
FZK12-12 V DC			X	X	X	X			
F4H12-12 V DC				X	X			X ¹⁾	
F4L12-12 V DC	X	X		X	X			X	X
FADS60	X	X		X	X	X			X
FFR61-230 V	X	X							X
FGM	X	X	X	X	X	X			X
FHK61-230 V	X			X	X	X		X	X
FHK61/8-24 V UC	X			X	X	X		X	X
FHK70-230 V	X			X	X			X	X
FKR70/1-10V	X	X				X	X		X
FKR70UD-230 V	X	X				X	X		X
FLC61NP-230 V	X	X	X	X	X	X	X		X
FLS70/1-10 V	X	X				X			X ²⁾
FLS70UD-230 V	X	X				X			X ²⁾
FMS61NP-230 V	X	X							X
FMZ61-230 V	X	X	X	X	X				X
FSB61NP-230 V	X	X		X	X		X		X ²⁾
FSB70-230 V	X	X		X	X		X		X ²⁾
FSG70/1-10V	X	X							X
FSR61-230 V	X	X	X	X	X	X	X		X
FSR61/8-24 V UC	X	X	X	X	X	X	X		X
FSR61NP-230 V	X	X	X	X	X	X	X		X
FSR61LN-230 V	X	X	X	X	X	X	X		X
FSR70-230 V	X	X	X	X	X	X	X		X
FSR70S-230 V	X	X	X			X	X		X
FTN61NP-230 V	X	X		X		X			X
FUA55LED	X	X		X	X	X			X
FUD61NP-230 V	X	X				X	X		X
FUD61NPN-230 V	X	X				X	X		X ²⁾
FUD70-230 V	X	X							X ²⁾
FUD70S-230 V	X	X							X ²⁾
FUT55D				X	X				
FZK61NP-230 V			X	X	X	X			
FZK70-230 V			X	X	X	X			
F2L61-230 V	X	X		X	X			X	X
F2L70-230 V	X	X		X	X			X	X

¹⁾ Only FTR55H, FTR55D and FUT55D ²⁾ Also controllable by activation telegrams from the FVS software