

# Eltako–FVS


## **License activation without internet connection**

Activation of the wireless visualisation and control software FVS via license activation file, if it is not possible to directly enter the license key in the FVS-safe via internet connection or on the PC via FVS-software.

## 1. Creation of a license request file

License request files will be created via CodeMeter control center. This program is integrated in the installation routine of the Eltako FVS-Software and can be opened via windows menue „start / all programs / CodeMeter / CodeMeter control central“.

- 1.1 In the CodeMeter control center you can see your existing licences on the left side. Please choose the „Full version“ of the available licenses. On the right side of the window „Empty license container“ will be displayed as status. Please press „Activate License“.



picture 1: CodeMeter control center


1.2 The wizard to activate the license will be started:



picture 2: CodeMeter Field Activation Service


To validate press „next“.

1.3 Move keyboard selection to „Create license request“ and validate with „Next“.



picture 3: create license request


1.4 Choose file name and location of the license request file in the next window.



picture 4: set location and file name

To confirm press „Commit“.

1.5 Now the license request file is created and saved in the chosen file.



picture 5: license request file is created

1.6 You have to save this created file on an USB stick to activate it from an internet-capable PC.


## 2. Collect the license

There are 2 ways to activate the license for the Eltako FVS software, it will be enlarged in the following subchapters. In both cases the requirement is to connect the USB stick with an internet-capable PC.

### 2.1. License activation in the browser

- 2.1.1 To activate the license request file please open the browser of a PC with internet connection and go to this site <http://codemeter.embedded-intelligence.de>. You will be redirected to the CodeMeter license center.


Please enter your license key for the Eltako FVS-software in the box „Ticket Id“. After that please press „Get Licenses“.



picture 6: CodeMeter license center


2.1.2 Please mark „Remote“ in the sector „Programming type“ and indicate the location of the license activation file.

In „Your licences“ you can see which license is involved.




picture 7: selection of the type of programming

2.1.3 After that press the button „Activate all my licenses“ to activate your license.




picture 8: activate license

Please confirm the message from webpage with „OK“.




picture 9: confirmation of the activation

### 2.1.4 Now a new file with an activated license will be created.




picture 10: license will be activated

### 2.1.5 Possibly the download of the newly created file will be blocked. Please click on the toolbar on the top to allow the download to start.




picture 11: download of the new license file

- 2.1.6 If problems encounter with downloading, the created file can be downloaded again afterwards via „Download update“.



picture 12: download file again

To confirm the download of the created file please press „Save“.




picture 13: download file

## 2.2. License activation via E-Mail

To activate the license via E-Mail please open a new E-Mail in your browser or your E-Mail program. Attach your key for the Eltako FVS software as well as the created license activation file and send this E-Mail to [fvs@eltako.de](mailto:fvs@eltako.de).


### 3. Update the license

- 3.1 Open the CodeMeter control center once more. Choose the license „Full version“ and press „Activate license“.




picture 14: CodeMeter control center

- 3.2 Choose „Import license update“ in the activation wizard and press „Next“.




picture 15: activation wizard

3.3 Indicate the path to the location of the created license file and press „Commit“.




picture 16: location of the license file

Now the license will be updated in the CodeMeter control center.




picture 17: license update

3.4 After the successful license update press „Finish“ to close the wizard.



picture 18: confirmation of the license update

You can see your activated Eltako FVS-license in the CodeMeter control center.



picture 19: activated license

After successful integration of your license, please minimize the window via close button in the upper right corner.