



## ADDITIONAL INFORMATION

### FTR86B-ws

EEP profile A5-10-06 or A5-10-06 + RPS must be selected for following Eltako actuators: FHK14, F4HK14, FAE14LPR, FAE14SSR, FHK61-230V (from week 38/17), FHK61U-230V (from week 38/17) and FHK61SSR-230V (from week 38/17).

If EEP A5-10-06 + RPS (special function) is selected, the buttons (+) and (-) can be taught-in in further actuators e.g. FSR14, FUD14, FSR61 or FUD61.