WIRELESS 4-WAY PUSHBUTTON WITH BATTERY IN E-DESIGN55 F4T55EB-





Wireless pushbutton with double rocker





languages: https://eltako.com/redirect/F4T55EB-

F4T55EB-







Wireless 4-way pushbutton in E-Design55, $80 \times 80 \, \text{mm}$ external dimensions, internal frame dimensions $55 \times 55 \, \text{mm}$, $15 \, \text{mm}$ high. Whisper quiet and with battery (lifetime 2-7 years).

Wireless pushbuttons with double rocker can transmit four evaluable signals: press two rockers up or down

The mounting plate can be screwed over a flush-mounting box with a screw spacing of 60 mm or screwed on a flat surface. The wireless pushbutton can be glued to the wall, on glass or on furniture using the enclosed adhesive foil.

F4T55EB-am	Wireless 4-way pushbutton with battery in E-Design55, anthracite mat	Art. No. 30055688	72,80 €/pc.
F4T55EB-pg	Wireless 4-way pushbutton with battery in E-Design55, polar white glossy	Art. No. 30055682	72,80 €/pc.
F4T55EB-pm	Wireless 4-way pushbutton with battery in E-Design55, polar white mat	Art. No. 30055683	72,80 €/pc.
F4T55EB-wg	Wireless 4-way pushbutton with battery in E-Design55, pure white glossy	Art. No. 30055685	72,80 €/pc.