

WIRELESS SWITCH 55 X 55 MM WITHOUT BATTERY AND WIRE FS55-wg



Wireless switch with single rocker



Manuals and documents in further languages:
<http://eltako.com/redirect/FS55-wg>

FS55-wg



Wireless switch, 80x80 mm external dimensions, internal frame dimensions 55x55 mm, 15 mm high. Generates the power for wireless telegrams itself when the rocker is pressed, therefore there is no connecting wire and no standby loss.

This wireless switch can be taught-in as an 'universal button' in the impulse switch relays of the series 61, 62 and 14. Press the wireless switch up or down, the switch position of the actuator changes each time it is pressed (toggling). If several radio switches or radio buttons are taught-in together, the wireless switch fulfills the function of a toggle switch.

FS55-wg	Wireless switch 55 x 55 mm without battery and wire, pure white glossy	Art. No. 30000598	55,40 €/pc.
---------	--	-------------------	-------------