



Wireless switch with single rocker



FS65E-wg



Wireless switch for single mounting 84x84x16 mm or mounting into the E-Design65 switching system. Generates the power for wireless telegrams itself when the rocker is pressed, therefore there is no connecting wire and no standby loss. With single rocker. Smart Home sensor.

This wireless switch can be taught-in as an 'universal button' in the impulse switch relays of the series 61, 62 and 14. Press the wireless switch up or down, the switch position of the actuator changes each time it is pressed (toggling). If several radio switches or radio buttons are taught-in together, the wireless switch fulfills the function of a toggle switch.

| | | |
|-----------------|---|----------------------------|
| FS65E-wg | Wireless switch without battery and wire, pure white glossy | No longer available |
|-----------------|---|----------------------------|