



Wireless pushbutton with intermediate frame and rocker (without frame)



Wireless pushbutton with intermediate frame and double rocker (without frame)

FT4B-



Wireless 4-way pushbutton 45 x 45 mm Niko Belgium. Generates the power for wireless telegrams itself when the button is pressed, therefore there is no connecting wire and no standby loss. With rocker and double rocker.

FT4B-cr	Wireless 2- or 4-way pushbutton 45x45 mm Belgium, w/o frame, niko cream, without battery and wire	EAN 4010312312995	47,20 €/pc.
FT4B-na	Wireless 2- or 4-way pushbutton 45x45 mm Belgium, w/o frame, niko anthracite, without battery and wire	EAN 4010312314180	47,20 €/pc.
FT4B-nw	Wireless 2- or 4-way pushbutton 45x45 mm Belgium, w/o frame, niko white, without battery and wire	EAN 4010312312902	47,20 €/pc.