

WIRELESS 4-WAY PUSHBUTTON FT4BS-WS



Wireless pushbutton with intermediate frame and rocker (without frame)



Wireless pushbutton with intermediate frame and double rocker (without frame)

FT4BS-ws

Wireless 4-way pushbutton 45 x 45 mm Belgium, Schneider-white. Generates the power for wireless telegrams itself when the button is pressed, therefore there is no connecting wire and no standby loss. With rocker and double rocker.



FT4BS-ws	Wireless 4-way pushbutton 45x45mm Belgium, Schneider-white	No longer available
----------	--	---------------------