



Wireless pushbutton with intermediate frame and rocker (without frame)



Wireless pushbutton with intermediate frame and double rocker (without frame)

FT4CH-



Wireless 4-way pushbutton for internal frame dimensions 60 x 60 mm, 15 mm high. Generates the power for wireless telegrams itself when the button is pressed, therefore there is no connecting wire and no standby loss. With rocker and double rocker. Also for cover frames from ABB Normelec and Hager.

FT4CH-hg	Wireless pushbutton without battery or wire, without frame, light grey	EAN 4010312300985	45,80 €/pc.
FT4CH-sz	Wireless pushbutton without battery or wire, without frame, black	EAN 4010312300992	45,80 €/pc.
FT4CH-w	Wireless pushbutton without battery or wire, without frame, white	EAN 4010312300978	45,80 €/pc.