

WIRELESS 2- OR 4-WAY PUSHBUTTON SWEDEN, WITHOUT FRAME FT4S-WS



Wireless pushbutton with rocker
(without frame)



Wireless pushbutton with
double rocker (without frame)



Manuals and documents in further
languages:
<https://eltako.com/redirect/FT4S-ws>

FT4S-ws



Wireless 2- or 4-way pushbutton 55 x 55 mm Sweden eljo white. Generates the power for wireless telegrams itself when the button is pressed, therefore there is no connecting wire and no standby loss.

FT4S-ws	Wireless 2- or 4-way pushbutton Sweden, without frame, eljo white	Art. No. 30000220	62,00 €/pc.
---------	--	-------------------	-------------