



22 016 001 - 1



## MODBUS meter M0 TT gateway over IP ZGW16WL-IP / ZGW16NI-IP

**Only skilled electricians may install this electrical equipment otherwise there is the risk of fire or electric shock!**

Temperature at mounting location: -20°C up to +50°C.  
Storage temperature: -25°C up to +70°C.  
Relative humidity: annual average value <75%.

### ZGW16WL-IP:

Modular device for DIN-EN 60715 TH35 rail mounting.

2 modules = 36 mm wide, 58 mm deep.

IP interface either via WLAN or LAN.

The WLAN connection uses the 2.4 GHz frequency band. The LAN connection is via RJ45 connector with 10/100Base-T

Only 0.9 watt standby loss.

### ZGW16NI-IP:

Modular device for DIN-EN 60715 TH35 rail mounting.

2 modules = 36 mm wide, 58 mm deep.

IP-Schnittstelle über WLAN.

Die WLAN-Verbindung nutzt das 2.4 GHz Frequenzband. Only 0.8 watt standby loss.

ZGW16WL-IP and ZGW16NI-IP hereinafter called 'ZGW16-IP'.

### Gateway with IP interface for ELTAKO Modbus electricity meters.

**The IP connection is via LAN or WLAN. The gateway transmits data from any ELTAKO Modbus electricity meter via the MQTT protocol and REST API. The data is transferred from the ZGW16-IP to any external MQTT broker.**

For more details about MQTT see: [www.mqtt.org](http://www.mqtt.org).

**The current meter values and a history can be viewed via the ELTAKO Connect app and web interface. Initial commissioning and configuration is possible via the ELTAKO Connect app and web interface. Firmware updates are done via the web interface. A REST API is available via the device's online product page.**

### Controls

The ZGW16-IP has a rotary switch with positions 1-10 and integrated LED (green/red).

When delivered, the LED flashes green, although the rotary switch must not be in position 1 or 10.

Once the initial commissioning is complete, the LED goes out.

### Factory reset

If the rotary switch is set to position 1 or 10, the LED lights up green continuously.

If the rotary switch is turned back and forth from position 1 5 times within 10 seconds, the ZGW16-IP is reset to factory settings and the delivery status is restored.

### Error indication

If data transfer to the MQTT broker is not possible (e.g. MQTT not configured or data connection interrupted), the LED lights up permanently red. The next time data is transferred successfully, the LED goes out.

If the LED flashes red, approx. 5 times per second, there is a HW error and the device must be replaced.

### Initial commissioning via ELTAKO Connect app

After the power supply to the ZGW16-IP has been established, a WLAN access point is provided.

**SSID: Eltako-ZGW16-IP**

**Password: zgw16-ip**

After connecting to the WLAN access point, the ELTAKO Connect app can be started.

The ZGW16-IP is automatically searched for and displayed in the ELTAKO Connect app.

When delivered, an access password must first be assigned.

The current meter values and a history can now be accessed under the menu item 'meters'.

You can find an explanation of the other configuration options later in the operating instructions.

### Initial commissioning and device configuration via web interface

Via WLAN: After the power supply to the ZGW16-IP has been established, a WLAN access point is provided.

**SSID: Eltako-ZGW16-IP**

**Password: zgw16-ip**

The IP address of the device is **192.168.4.1 (WLAN) or 192.168.5.1 (LAN)**

Via LAN (ZGW16WL-IP only): when delivered, the LAN port has the IP address 192.168.5.1

To do this, enter <http://192.168.5.1> (LAN) or <http://192.168.4.1> (WLAN) in the address.

In the delivery state, an access password must be assigned first.

Welcome to FGW14-IP

Please set a new password.

Password

\*\*\*\*\*

Confirm Password

\*\*\*\*\*

Set Password

Connection to the WLAN access point

**SSID: Eltako-ZGW16-IP**

**Password: zgw16-ip**



After logging in, further configuration can be performed using the menus:

- system
- network
- MQTT
- devices
- Modbus

If there is no access to the website for 4 hours, the user is automatically logged out.

## System

Here the ZGW16-IP can be assigned a suitable name with up to 16 characters.

The screenshot shows the 'Device-Settings' page. It contains the following fields and controls:

- Device-Name:** A text input field containing 'ZGW16NI-IP' and a 'Save' button.
- Type:** A text input field containing 'ZGW16NI-IP'.
- Serial number:** A text input field containing '5C54F8C2-D361-4015-9752-4BA4C88A8F44'.
- Version:** A text input field containing '0.0.0'.

It is also possible to carry out a FW update, change the access password and reset the device to the delivery status.

The system time can be set via NTP (only with an existing Internet connection) or manually.

The screenshot shows the 'Time-Settings' page. It contains the following fields and controls:

- Date/Time:** A text input field containing '24.04.2024 21:37'.
- Retrieve time from NTP-Server:** A checkbox labeled '(NTP active)' which is checked.
- NTP Server:** A text input field containing 'pool.ntp.org'.
- Save:** A 'Save' button.
- Footnote:** A small text note: 'If the time is obtained from an NTP server, the changes will only become active after a short time. A reload of the page is then necessary to make the changes visible.'

## network

The LAN configuration is only possible with the model ZGW16WL-IP.

If WLAN is to be used, a connection to an existing WLAN (Station-Mode) can be configured. This deactivates the access point of the ZGW16.

The screenshot shows the 'Network' configuration page for the 'LAN' interface. It contains the following fields and controls:

- Interface:** 'LAN'.
- Disable LAN interface:** A checkbox that is unchecked.
- DHCP:** A checkbox labeled 'active' that is unchecked.
- IP-Address:** A text input field containing '192.168.5.1'.
- Subnet-Mask:** A text input field containing '255.255.255.0'.
- Standard-Gateway:** A text input field containing '192.168.5.254'.
- DNS-Server:** A text input field containing '192.168.5.254'.
- Alternative DNS-Server:** A text input field containing '192.168.5.254'.
- Save:** A 'Save' button.

The screenshot shows the 'Network' configuration page for the 'WLAN' interface. It contains the following fields and controls:

- Interface:** 'WLAN'.
- Disable WIFI interface:** A checkbox that is unchecked.
- SSID:** A text input field containing 'Home' and a 'Search for networks' button.
- Password:** A text input field containing '\*\*\*\*\*'.
- DHCP:** A checkbox labeled 'active' that is checked.
- IP-Address:** A text input field containing '192.168.178.108'.
- Subnet-Mask:** A text input field containing '255.255.255.0'.
- Standard-Gateway:** A text input field containing '192.168.178.1'.
- DNS-Server:** A text input field containing '192.168.178.1'.
- Alternative DNS-Server:** A text input field containing '0.0.0.0'.
- Save:** A 'Save' button.

The WLAN and the LAN interface can each be deactivated. Under no circumstances should both interfaces be deactivated, as access to the device from the network is no longer possible.

## MQTT

Under 'MQTT', a specific MQTT broker can be defined as the target address for the electricity meter data.

mqtt:// or mqtts:// can be used. The port can be freely selected in the range 1 - 65535.

If provided by the broker, a certificate can optionally be stored.

The name for the MQTT topic (Default ZGW16-IP) can also be adjusted.

### MQTT-Broker-Settings

**Broker URI**  
mqtt://   
MQTT connection established

**Port**

**Client-ID**

**User**

**Password**

**Certificate**  
unconfigured

**Topic**

The maximum data rate depends on the network quality and the response time of the broker.

## Devices

Under 'Devices' the detected ELTAKO Modbus electricity meter is displayed on the RS485 bus with the bus address and the meter type.

Die eingestellte Bus-Adresse am ELTAKO Modbus-Stromzähler muss 1 betragen, ansonsten wird der ELTAKO Modbus-Stromzähler nicht erkannt. Zusätzlich kann hier das weiterleiten der Zählerdaten per MQTT aktiviert werden.

### Devices

Bus-Address	Forward to MQTT	Name	Device Type
1	<input checked="" type="checkbox"/>	Solar-System	DSZH02MOD

The current meter values and the history are visible by opening the device display.


**The historical data is stored locally on the ZGW16-IP.**

### Devices

Bus-Address	Forward to MQTT	Name	Device Type
1	<input checked="" type="checkbox"/>	Solar-System	DSZH02MOD


Voltage of L1 to N	Voltage of L2 to N	Voltage of L3 to N	L1 Current
240,9 Volt	0,0 Volt	0,0 Volt	0,0 A
24.04.2024 21:50	24.04.2024 21:50	24.04.2024 21:50	24.04.2024 21:50
L2 Current	L3 Current	L1 active power	L2 active power
0,0 A	0,0 A	0,0 Watt	0,0 Watt
24.04.2024 21:50	24.04.2024 21:50	24.04.2024 21:50	24.04.2024 21:50
L3 active power	L1 power factor	L2 power factor	L3 power factor
0,0 Watt	1,0	0,0	0,0
24.04.2024 21:50	24.04.2024 21:50	24.04.2024 21:50	24.04.2024 21:50
Total active power	Total power factor	Total imported active energy	Total exported active energy
0,0 Watt	1,0	0,0 kWh	0,0 kWh
24.04.2024 21:50	24.04.2024 21:50	24.04.2024 21:50	24.04.2024 21:50



## Technical data

WLAN	2,4 GHz
Transmission power	max. 100 mW
Standby loss (activ power):	0.9 W (ZGW16WL-IP) 0.8 W (ZGW16NI-IP)

## Typical connection



## Manuals and documents in further languages:



[https://eltako.com/redirect/FGW14WL-IP\\_FGW14W-IP](https://eltako.com/redirect/FGW14WL-IP_FGW14W-IP)



Hereby, ELTAKO GmbH declares that the radio equipment type ZGW16WL-IP / ZGW16NI-IP is in compliance with Directive 2014/53/EU.

The full text of the EU declaration of conformity can be accessed via the QR code or the internet address under 'Documents'.

### Must be kept for later use!

We recommend the housing for operating instructions GBA14.

### Eltako GmbH

D-70736 Fellbach

#### Technical Support English:

+49 711 94350025

technical-support@eltako.de

eltako.com