


Wireless actuator

Impulse switch with integr. relay
function with current measurement
FSR61VA-10A**Only skilled electricians may install
this electrical equipment otherwise
there is the risk of fire or electric
shock!**Temperature at mounting location:
-20°C up to +50°C.
Storage temperature: -25°C up to +70°C.
Relative humidity:
annual average value <75%.**valid for devices from production week
03/13** (see bottom side of housing)1 NO contact not potential free 10A/250V
AC, incandescent lamps up to 2000 watts,
off delay with switch-off early warning
and switchable pushbutton permanent
light. With integrated current measure-
ment up to 10A. Bidirectional wireless
and repeater function are switchable.
Only 0.7 watt standby loss.For installation.
45mm long, 55mm wide, 33mm deep.
Supply voltage 230V.**This wireless actuator features state-of-
the-art hybrid technology that we
developed: we combined the wear-free
receiver and evaluation electronics and
a bistable relay.**Apparent power is measured by the
integrated current measurement from
approx. 10VA to 2300VA when the
contact is closed. A wireless telegram is
transmitted into the Eltako wireless net-
work within 30 seconds after switching
on the load or after a change in power by
min 5% and cyclically every 10 minutes.**Evaluation on the computer with Eltako
Wireless Building Visualisation and
Control Software GFVS or with energy
consumption indicators FEA55LED or
FEA55D.** GFVS-Energy supports up to
100 transmitter modules and GFVS 3.0
up to 250 transmitter modules.From production week 03/2013
bidirectional wireless and **repeater**
function can be switched on. Every
change in state and incoming central
command telegrams are confirmed by a
wireless telegram. This wireless telegram
can be taught-in in other actuators, in
the GFVS software and in FUA55 universal
displays.**Scene control:** several FSR61s can be
switched on or off in a scene by one of
the four control signals of a double-
rocker pushbutton taught-in as scene
pushbutton.

Function rotary switches


**With the top rotary switch** in the setting
LRN up to 35 wireless pushbuttons can
be assigned therefrom one or more
central control pushbuttons. In addition
wireless window/door contacts with the
function N/O contact or N/C contact
while the window is open. The required
function of the impulse switch with inte-
grated relay function can then be selected:**ER** = switching relay**ESV** = impulse switch.

Possibly with off delay, then:

- + = ESV with pushbutton permanent light
- + = ESV with switch-off early warning
- + = ESV with pushbutton permanent light and switch-off early warning

If the permanent light function is
switched on, the function can be activated
by pressing the pushbutton for longer
than 1 second. This function switches off
automatically after 2 hours or by pressing
the pushbutton.**If the switch-off early warning** is
switched on, the light starts to flicker
approx. 30 seconds before time-out.
This is repeated three times at decreasing
time intervals. If both switch-off early
warning and pushbutton permanent
light are switched on, switch-off
early warning is activated before auto-
matic switch-off of the permanent light.
The function **ESV on the bottom rotary
switch** sets the off delay from 2 to 120
minutes. In setting ∞ normal impulse
switch function ES without off delay,
without pushbutton permanent light and
without switch-off early warning.In setting ER = switching relay of the
other rotary switch, this 2nd rotary switch
fulfils a safety and power saving function
in the settings except ∞. If the switch-
off command is not recognised, e.g.
since the pushbutton is jammed or it was
pressed too quickly, the relay switches off
automatically on expiry of a time
adjustable between 2 and 120 seconds.
When a FTK is taught-in, this time function
is turned off.**Twilight switch** with taught-in wireless
outdoor brightness sensor FAH and then
in function setting ESV. In time setting
120 the contact opens with a delay of
4 minutes if the brightness level is
sufficient. In time setting ∞ the contact
opens instantly. The local and central
pushbutton control is still possible.**Motion detection** with taught-in wireless
motion detector FBH in function setting
ER. The device switches on when
motion is detected. If no more motion is
detected, the contact opens after the
time delay setting $t = 2$ to 255 seconds
(Position ∞).**Outdoor brightness sensor and motion
detector** can be used together with
function setting ER to evaluate motion
only in darkness. If the FAH detects bright-
ness, the contact opens immediately.**When teaching-in**, the switching
threshold is also taught-in: between
break of twilight and complete darkness.**The LED** performs during the teach-in pro-
cess according to the operation manual.
It shows wireless control commands by
short flickering during operation.

Typical connection



Technical data

Rated switching capacity	10A/250V AC
Incandescent lamp and halogen lamp load ¹⁾	2000W / 230V
Fluorescent lamp load with KVG* in lead-lag circuit or non compensated	1000VA
Fluorescent lamp load with KVG* 500VA shunt-compensated or with EVG*	500VA
Compact fluorescent lamps with EVG* and energy saving lamps	15x7W / 10x20W
Local control current at 230V control input	3.5 mA
Max. parallel capacitance (approx. length) of local control lead at 230V AC	0.01 μF (30m)
Standby loss (active power)	0.7 W

¹⁾ Applies to lamps of max. 150W.* EVG = electronic ballast units;
KVG = conventional ballast units

Teaching-in wireless sensors in wire- less actuators

**All sensors must be taught-in in actuators
so that they can detect and execute
their commands.**

Teaching-in actuator FSR61VA-10A

The teach-in memory is empty on delivery
from the factory. If you are unsure whether
the teach-in memory contains some-
thing or not, **you must first clear the
memory contents completely:**Set the upper rotary switch to CLR. The
LED flashes at a high rate. Within the

next 10 seconds, turn the lower rotary switch three times to the right stop (turn clockwise) and then turn back away from the stop.

The LED stops flashing and goes out after 2 seconds. All taught-in sensors are cleared, the repeater and the confirmation telegram are switched-off.

Clear individual taught-in sensors in the same way as in the teach-in procedure, except that you set the upper rotary switch to CLR instead of LRN, and operate the sensor. The LED previously flashing at a high rate goes out.

Teaching-in sensors

1. Setting of the lower rotary switch to the desired teaching-in function:

The flashing of the LED as soon as a new setting range has been reached when turning the rotary switch helps to find the desired position reliably.

Left stop 2 = teach-in 'central OFF' and FTK and Hoppe window handle as NC contact;

6 = teach in scene pushbutton; a complete double rocker pushbutton is assigned automatically;

60 = teach-in pushbutton 'ON/OFF';

Pos. 120 = teach-in pushbutton as NC contact;

Right stop ∞ = teach-in 'central ON' and FTK and Hoppe window handle as NO contact

The FBH requires no teach-in function. Several FBH can be taught-in.

Caution! Either the FBH or the FTK can be taught-in.

When a **FAH is taught-in as twilight sensor**, the position of the bottom rotary switch defines the threshold: 2 = complete darkness and 120 = break of twilight.

2. Set the upper rotary switch to LRN. The LED flashes at a low rate.

3. Operate the sensor which should be taught-in. The LED goes out.

To teach-in further sensors, turn the upper rotary switch briefly away from position LRN. Continue the procedure from pos 1.

After teach-in, set the rotary switches of the actuators to the required function.

Teaching-in scenes:

Four scenes can be saved by a scene pushbutton previously taught-in.

1. Switch on/off impulse relays
2. The switching state is saved by pressing one of the four rocker ends of a doublerocker scene pushbutton for 3-5 seconds.

Switching on/off repeater:

Set the upper rotary switch to LRN. Switch on supply voltage. The repeater is switched on or off. When the power supply is switched on, the LED lights up for 2 seconds = repeater off (as-delivered state) or 5 seconds = repeater on to indicate the state.

Switch-on confirmation telegrams:

For deliveries ex-works the confirmation telegrams are switched-off. Set the upper rotary switch to CLR. The LED flashes nervously. Now within 10 seconds turn the bottom rotary switch 3 times to the left (anticlockwise) and then back away. The LED stops flashing and goes out after 2 seconds. The confirmation telegrams are switched-on.

Switch-off confirmation telegrams:

Set the upper rotary switch to CLR. The LED flashes nervously. Now within 10 seconds turn the bottom rotary switch 3 times to the left (anticlockwise) and then back away. The LED goes out immediately. The confirmation telegrams are switched-off.

Teaching-in feedback of this actuator in other actuators:

set the upper rotary switch to CLR, switch on supply voltage, 'switch on' is sent. Set the upper rotary switch to ESV, switch on supply voltage again, 'switch off' is sent.

Teaching- in feedback of other actuators in this actuator:

teaching-in feedback other actuators is only reasonable if this actuator is run in function setting ESV. 'switch on' will be taught-in in position 'central ON'. 'switch off' will be taught-in in position 'central OFF'. After teach-in in the function ESV and the off-delay will be set.

Teaching-in FSR61VA in FEA55 or GFVS software:

When switching on the supply voltage a teach-in telegram, a power telegram and a switching state telegram will be transmitted.



When an actuator is ready for teach-in (the LED flashes at a low rate), the very next incoming signal is taught-in. Therefore, make absolutely sure that you do not activate any other sensors during the teach-in phase.

Must be kept for later use!

Eltako GmbH

D-70736 Fellbach

+49 711 94350000

www.eltako.com

01/2013 Subject to change without notice.