



30 000 560 - 2

Wireless sensor

Wireless temperature controller
FTR55DSB-wg with display

Temperature at mounting location:
-20°C up to +50°C.
Storage temperature: -25°C up to +70°C.
Relative humidity:
annual average value <75%.

**valid for devices from production week
21/19** (see bottom side of housing)

**Wireless temperature controller with
display pure white glossy for single
mounting 80x80x22 mm or mounting into the
E-Design55 switching system. With solar
cell and battery (lifetime 3-5 years).
Smart Home sensor.**

Alternatively, the device can be powered
by a 12V DC switching power supply unit
SNT61-12V/6W fitted in a flush-mounted box
behind the sensor. If the connecting cable is
not needed, it can be cut off. This means the
sensor requires no installation depth behind
the mounting plate. It can be screwed to any
flat surface.

We recommend stainless-steel countersunk
screws 2.9x25 mm, DIN 7982 C, for screw
connections. Both with rawl plugs 5x25 mm
and with 55mm switch boxes.

Set of 2 stainless-steel countersunk screws
2.9x25 mm and plugs 5x25 mm are enclosed.

The sensor sends a message every
100 seconds to the Eltako wireless network at
an actual temperature change of minimum
0.3°C. The bistable display is updated.

A change in reference temperature is sent
immediately. The display is updated.

If there is no change, a status report is sent
every 17 minutes.

Measurement accuracy is approx. 1°C.

Installation:

Screw on the holding plate including its
electronics. Then snap on the frame, remove
the battery insulation, and mount the cover
panel together with the display and solar
cells.

Normal display: The upper display shows the
day reference temperature presetting of
20°C in small characters preceded by a d
(=day). The lower display shows the actual
temperature in large characters, e.g. 21.5°C.
Adjust the day reference temperature from
+8°C to +40°C in steps of 0.5°C by pressing
the ▲ and ▼ keys. Several key operations
are accumulated.

The new reference temperature appears
in the display in large digits after approx.
2 second. After a further approx.
6 seconds, the display returns to normal mode.

Night reduction can also be activated and
adjusted by pressing the ▲ and ▼ keys.

Activation is by pressing both keys
simultaneously and briefly. The top of the
display shows the night reference tempera-
ture in small digits preceded by 'n' (= night).

The presetting is a value which is 4°C lower
than the day reference temperature.

Terminate the night reduction function by
briefly pressing the two keys simultaneously.

The temperature reduction value can be
changed in steps of 1°C by pressing the ▲
and ▼ keys as long as the night reduction
function is activated. Here too, several key
operations are accumulated. The new
temperature reduction value is shown in the
display in large digits after approx. 2 seconds.

After a further approx. 6 seconds, the display
returns to night reduction mode.

Terminate the night reduction function by
briefly pressing the two keys simultaneously.

Energy storage or battery empty:

If the energy accumulator or battery voltage
drops below 2.7 V, the display shows 'LoAd'.

To replace the CR2032 3 V button cell,
simply remove the cover panel along with the
display and solar cells. After replacing the
batteries, snap the cover panel back on
together with the display and solar cells.

Teach-in:
Press and hold down one of the two keys
▲ or ▼ for longer than 4 seconds to
teach in the sensor in a wireless actuator
switched to teach-in mode.
If the temperature controller is taught-
in in a FR62, the teach-in mode is
automatically closed and blocked.

Unblock teaching mode of the FR62:
1. Disconnect and reconnect the power
supply of the Tap-radio actuator.
2. Press briefly the both buttons ▲ and ▼
simultaneously.
n will be displayed at the top of the
display. To switch back to day (d) press
briefly the both buttons ▲ and ▼ again
simultaneously.

EEP: A5-10-06
Teach-in telegram: 0x40300D87
Data telegram:
Data_byte0 = 0x0F
Data_byte1 = actual temperature 0xFF..0x00
corresponds to 0..40°C
Data_byte2 = Setpoint temperature
0x00..0xFF corresponds to 0..40°C
EEP: A5-38-08
Teach-in telegram: 0xE0400D80
Data telegram: OFF = 0x01000008
ON = 0x01000009
Hysteresis: 1°

**The crossed-out waste container indicates
that batteries may not be disposed with
other household or commercial waste.**



**Attention: Danger of explosion
if battery is replaced improperly.
Only replace it by an equivalent
type!**



enocean®
THE UNIQUE WIRELESS PROFESSIONAL
SMART HOME STANDARD

Frequency	868.3 MHz
Transmit power	max. 10 mW

**Hereby, Eltako GmbH declares that the radio
equipment type FTR55DSB-wg is in
compliance with Directive 2014/53/EU.
The full text of the EU declaration of
conformity is available at the following
internet address: eltako.com**

Must be kept for later use!

Eltako GmbH
D-70736 Fellbach
Technical Support English:
☎ +49 711 94350025
✉ technical-support@eltako.de
eltako.com

4/2020 Subject to change without notice.