


Function rotary switches



Further settings can be made using the PC Tool PCT14.

Housing for operating instructions GBA14 page 1-40.

FTD14



**Telegram duplicator for the Eltako RS485 bus with exchangeable antenna.
Only 0.5 watt standby loss.**

Modular device for DIN-EN 60715 TH35 rail mounting. 1 module = 18 mm wide, 58 mm deep.

Connection to the Eltako-RS485 bus. Bus cross wiring and power supply with jumper. Operation in conjunction with FAM14 or FTS14KS.

The telegrams of taught-in IDs are duplicated and directly sent into the Eltako wireless network with a new output ID. These wireless telegrams can be specifically taught-in in decentralized actuators.

A total of 120 memory locations are available.

The upper rotary switch is used to selectively transmitting a wireless telegram. In normal operation, it is set to RUN.

The bottom rotary switch is used for teaching-in and deleting IDs. In normal operation, it is set to RUN.

The red LED below the upper rotary switch performs during the teaching-in process.

The green LED below the lower rotary switch lights up briefly when a wireless telegram is transmitted.

The enclosed small antenna can be replaced with a wireless antenna FA250 with magnetic base and cable.

FTD14	RS485 telegram duplicator	EAN 4010312315705	87,30 €/pc.
-------	---------------------------	-------------------	--------------------