

## **RS485 BUS TELEGRAM DUPLICATOR FTD14**





## **Function rotary switches**



Further settings can be made using the PC Tool PCT14 (see page 1-5).



Manuals and documents in further languages:

https://eltako.com/redirect/FTD14

Housing for operating instructions GBA14 page 1-50.

## FTD14





Telegram duplicator for the ELTAKO RS485 bus with exchangeable antenna. Only 0.5 watt standby loss.

Modular device for DIN-EN 60715 TH35 rail mounting.

1 module = 18 mm wide, 58 mm deep.

Connection to the ELTAKO RS485 bus. Bus cross wiring and power supply with jumper. Operation in conjunction with FAM14 or FTS14KS.

The telegrams of taught-in IDs are duplicated and directly sent into the ELTAKO wireless network with a new output ID. These wireless telegrams can be specifically taught-in in decentralized actuators.

A total of 120 memory locations are available.

**The upper rotary switch** is used to selectively transmitting a wireless telegram. In normal operation, it is set to RUN.

**The bottom rotary switch** is used for teaching-in and deleting IDs. In normal operation, it is set to RUN. **The red LED** below the upper rotary switch performs during the teaching-in process.

**The green LED** below the lower rotary switch lights up briefly when a wireless telegram is transmitted. The enclosed small antenna can be replaced with a wireless antenna FAG55E- or FA250 with magnetic base and cable.

FTD14	RS485 bus telegram duplicator	Art. No. 30014057	92,60 €/pc.